


6. Setting up your GPS for use

This only needs to be done *once* – upon receipt of GPS units, prior to use in field survey. After settings are complete, NO further changes should be made. Properly setting up your GPS helps to ensure that standard GPS settings are used in every country.

Standard Settings Procedure

This can be done indoors, no satellite signal is needed

1. Switch on GPS by pressing **Power** key
2. Press **Page** key several (4) times until the **Main Menu** screen appears



3. Press the **Down / Up** keys to select **Setup**
4. Press the **Enter** key to open the **Setup Menu**
5. Press the **Down / Up** keys to select **Units**. The **Units** option contains the key settings that you should check / change.
6. Use the **Enter** key to select a category, then the **Up / Down** Keys to select the correct option within a category. Finally, press **Enter** key to save change.
7. Repeat step 6 for each Units category

The required Units settings are:

Position Format:	Hddd.ddddd° [this means that latitude / longitude coordinates are given in decimal degrees]
Map Datum:	WGS 84
Distance/Speed:	Metric
Elevation:	Meters
Vertical Spd:	m/min
Depth:	Metric